



HMT.04.10200
KTM 1290 Super Adventure R
Sound Bomb Mini Horn Mounting Bracket

Thank you for choosing DENALI

We know you would rather be riding your bike than wrenching on it, so we go the extra mile to make sure our instructions are clear and as easy to understand as possible. If you have any questions, comments, or suggestions don't hesitate to give our gear experts a call at 401.360.2550 or visit WWW.DENALIELECTRONICS.COM

Please Read Before Installing

DENALI products should always be installed by a qualified motorcycle technician. If you are unsure of your ability to properly install a product, please have the product installed by your local motorcycle dealer. DENALI takes no responsibility for damages caused by improper installation. **Caution:** When installing electronics it is extremely important to pay close attention to how wires are routed, especially when mounting products to the front fender, front forks, or fairing of your motorcycle. Always be sure to turn the handlebars fully left, fully right, and fully compress the suspension to ensure the wires will not bind and have enough slack for your motorcycle to operate properly.


Installation Tips

We strongly recommend using medium strength liquid thread locker on all screws, nuts, and bolts. It is also important to ensure that all hardware is tightened to the proper torque specifications as listed in your owner's manual. For included accessory hardware please refer to the default torque specifications provided below. Inspect all hardware after the first 30 miles to ensure proper torque specifications are maintained.

Bolt Size	in-lbs	ft-lbs	Nm
M3	10.0 in-lbs	-	1.0 Nm
M4	23.0 in-lbs	-	2.5 Nm
M5	44.5 in-lbs	3.5 ft-lbs	5.0 Nm
M6	78.0 in-lbs	6.5 ft-lbs	9.0 Nm
M8	-	13.5 ft-lbs	18.0 Nm
M10	-	30.0 ft-lbs	41.0 Nm
M12	-	52.0 ft-lbs	71.0 Nm

Hardware Sizing Guide

Not sure what size bolt you have? Use this ruler to measure screws, bolts, spacers, etc. Remember, the length of a screw or bolt is measured from the start of the "mounting surface" to the end of the screw, so only include the screw head when measuring countersunk screws.



What's In The Box?




Kit Contents

- (a) M6 x 45mm Flanged Hex Head Screw DIN 6921.....Qty 1
- (b) M6 Washer DIN 125.....Qty 1
- (c) Sound Bomb Mini Horn Mounting Bracket.....Qty 2

- (d) Spacer OD:12.7mm ID: 6.5mm L: 14.3mm.....Qty 1

Compatibility: SoundBomb Mini Horn

Tools Required: 10mm wrench



1.1 - Location Prep & Installation

Step One: Locate the Sound Bomb Mini Horn bracket mounting location on the right hand side of the bike and remove the factory bolt.

Step Two: Secure the Horn Mount in place starting with the Spacer (d) then both Flat Brackets (c), Washer (b) and attach using the M6x45mm Flanged Hex Head Screw (a).

Note: The Flat Brackets (c) should be rotated to the right roughly 45° to be able to mount the Sound Bomb Mini horn in the right position.

Step Three: Mount the Sound Bomb Mini Horn to the open mounting hole on the flat bracket and secure it using the horn's provided hardware. The horn should end up tucked below the right side fairing. After you find the right angle and position for the mount and horn, properly tighten all hardware.