



Upper Light Mount
 Ducati Multistrada V4
 LAH.22.10800

Thank you for choosing DENALI

We know you would rather be riding your bike than wrenching on it, so we go the extra mile to make sure our instructions are clear and as easy to understand as possible. If you have any questions, comments, or suggestions don't hesitate to give our gear experts a call at 401.360.2550 or visit WWW.DENALIELECTRONICS.COM

Please Read Before Installing

DENALI products should always be installed by a qualified motorcycle technician. If you are unsure of your ability to properly install a product, please have the product installed by your local motorcycle dealer. DENALI takes no responsibility for damages caused by improper installation. **Caution:** When installing electronics it is extremely important to pay close attention to how wires are routed, especially when mounting products to the front fender, front forks, or fairing of your motorcycle. Always be sure to turn the handlebars fully left, fully right, and fully compress the suspension to ensure the wires will not bind and have enough slack for your motorcycle to operate properly.


Installation Tips

We strongly recommend using medium strength liquid thread locker on all screws, nuts, and bolts. It is also important to ensure that all hardware is tightened to the proper torque specifications as listed in your owner's manual. For included accessory hardware please refer to the default torque specifications provided below. Inspect all hardware after the first 30 miles to ensure proper torque specifications are maintained.


Bolt Size	in-lbs	ft-lbs	Nm
M3	10.0 in-lbs	-	1.0 Nm
M4	23.0 in-lbs	-	2.5 Nm
M5	44.5 in-lbs	3.5 ft-lbs	5.0 Nm
M6	78.0 in-lbs	6.5 ft-lbs	9.0 Nm
M8	-	13.5 ft-lbs	18.0 Nm
M10	-	30.0 ft-lbs	41.0 Nm
M12	-	52.0 ft-lbs	71.0 Nm

Hardware Sizing Guide

Not sure what size bolt you have? Use this ruler to measure screws, bolts, spacers, etc. Remember, the length of a screw or bolt is measured from the start of the "mounting surface" to the end of the screw, so only include the screw head when measuring countersunk screws.



What's In The Box?




Kit Contents

- (a) Radiator Cross Bar Mount (LAH.22.10800-01).....Qty 1
- (b) Front Light Mount DS (LAH.22.10800-02).....Qty 1
- (c) Front Light Mount PS (LAH.22.10800-03).....Qty 1
- (d) Front Radiator Spacer (LAH.22.10800-04).....Qty 2
- (e) M6 x 70mm Button Head Screw.....Qty 2
- (f) M5 x 15mm Button Flange Head Screw.....Qty 4

Tools Required:


- (a) Allen Key Set
- (b) Torx Bit set

1. Installing The Light Mount



1.1 - Mounting Location


Step One: Identify the mounting location, which is at the OE auxillary light mounting points on the front of the bike. Notice on the inside of each of the side fairings, there are brass threaded holes that will be utilized.



1.2 - Installing the Side Mounts

Step One: Remove the lower radiator mounting bolts on both sides.

Step Two: On each side, loosely install the side mounting brackets using the included M5 x 16mm hardware.



1.3 - Installing the Cross Bar

Step One: Position the spacers between the side brackets and the lower radiator mount. The smaller end of the spacer will fit into the lower radiator mount. Position the crossbar over the side mounts as shown and using the included the M6 x 70mm screws, thread the screws through the cross bar, side mount, and spacer into the lower radiator

Step Two: Finish tightening the side mount screws.